



The European voice of the
adhesive and sealant industry

These seminar proceedings and the graphic elements contained herein are under copyright of its owner(s). Please do not distribute without prior consent.

SAFE ADHESIVES FOR SAFE FOOD



Migration testing approaches
for adhesives

André Weiss, Manager Instrumental Analytics, Food
Safety, Henkel

1. Legal Background / Risk Assessment


1.1 Framework Regulation

- Framework Regulation (EC) No 1935/2004
- Article 3
- Materials and articles [...] shall be manufactured in compliance with good manufacturing practice so that, under normal and foreseeable conditions of use, they do not transfer their constituents to food in quantities which could:
 - endanger human health
 - bring about an unacceptable change in the composition of the food
 - bring about a deterioration in the organoleptic characteristics thereof
- Rationale for risk assessment

1. Legal Background / Risk Assessment

1.2 Risk Assessment

- Evaluation of adhesives via risk management



- Substance transfer from adhesive into foodstuff has to be evaluated:
 - Exposure → via worst-case **calculation**, migration **modelling**, **analytical** tests
 - Hazard → via **toxicological** assessments

1. Legal Background / Risk Assessment

1.2 Risk Assessment

- Evaluation of adhesives via risk management



- Substance transfer from adhesive into foodstuff has to be evaluated:
 - Exposure → via worst-case **calculation**, migration **modelling**, **analytical** tests
 - Hazard → via **toxicological** assessments

1. Legal Background / Risk Assessment

1.3 Worst-case calculation

- Calculate maximum transfer of substances
 - Critical parameters must be known
 - Amount of substance in the adhesive
 - Amount of adhesive used in the packaging material
 - Ratio of packaging material to packed food
 - Assume 100% transfer
-
- + Easy and fast, no chemical analysis required
 - Difficult for reactive systems, difficult for gas phase transfer
 - No unknown components




1. Legal Background / Risk Assessment

1.4 Migration Modelling

- Evaluate transfer via computer simulation
- Critical parameters must be known
 - Basic parameters (concentration, O:V ratio)
 - Layer thickness
 - Storage conditions
- + More realistic than worst-case calculation
- + No chemical analysis required
- No unknown components

Example: LDPE, Migration: 10d @ 60°C, MW 501-750 g/mol



JRC Science and Policy Reports, DRAFT for stakeholder consultaion, Technical guidelines for compliance testing – Annexes, 24/08/2016

1. Legal Background / Risk Assessment

1.5 Extraction


- Extraction under severe conditions
 - Organic solvent
 - Elevated temperature
- Analysis of extract
 - + Unknown components
 - + Results overestimate real migration
 - Chemical analysis required



1. Legal Background / Risk Assessment

1.6 Migration studies

- Migration under defined conditions
- Parameters to be known
 - Storage conditions
 - Type of foodstuff
- Analysis of migration solution
 - + Most realistic results
 - + Unknown components
 - Time consuming



1. Legal Background / Risk Assessment

1.7 Plastics Regulation

- Commission Regulation (EU) 10/2011 – Plastics Regulation
- Migration testing conditions described in detail
- Often referred to as migration testing conditions for all FCM
- Only applicable for plastic materials and articles (including plastic layers in multi-material multi-layer materials)
 - Adhesives are not within the scope of the Plastics Regulation
 - JRC Technical guidelines for compliance testing: “[...] only applicable to plastic materials and articles [...]”
- Other approaches needed for non plastics!

1. Legal Background / Risk Assessment

1.8 Migration testing for non plastics

- Migration testing guidelines for non plastics
- FEICA guidance paper “Migration testing of adhesives intended for food contact materials”, 27 May 2016
 - Typical adhesive systems in food contact application
 - Material-specific properties to be considered
 - Test procedures and evaluation of test results
 - Analytical challenges

2. Approaches for adhesive testing

2.1 Overview


- Wide range of applications, complex chemistry

Polyurethane adhesives	Adhesives based on natural polymers	Dispersions/emulsions
Coldseals	Heatseals	Hotmelts

2. Approaches for adhesive testing

2.2 Polyurethane adhesives


- Laminating adhesive, e.g. for flexible packaging
- Plastic multi-layer materials are subject to Plastics Regulation
 - Migration testing according to Regulation (EU) 10/2011
- Direct testing not possible (reactive adhesive system)
- Tests on final structure or model systems
 - Expected application (filling good, storage conditions)
 - Correct curing conditions



2. Approaches for adhesive testing

2.2 Polyurethane adhesives






- Monolayers should be tested separately
 - Distinguish between migration of adhesive and monolayer compounds
- Example
 - Polyolefin Oligomeric Saturated Hydrocarbons (POSH) from CPP monolayer



2. Approaches for adhesive testing

2.2 Polyurethane adhesives

- False-positive results/analytical artefacts
 - Primary aromatic amines (PAA) via photometric method
 - Sum parameter




Test solution

2. Approaches for adhesive testing

2.2 Polyurethane adhesives

- False-positive results/analytical artefacts
 - PAA via specific HPLC method
 - Retention time and UV spectrum allow for unequivocal assignment



2. Approaches for adhesive testing


2.2 Polyurethane adhesives

- False-positive results/analytical artefacts
 - PAA: Comparison between photometric and HPLC method
 - Example
 - CPP monolayer, 3% acetic acid, retort conditions
 - Photometric: >> 10 µg/kg
 - HPLC: not detectable

2. Approaches for adhesive testing

2.2 Polyurethane adhesives


- False-positive results/analytical artefacts
 - Example
 - Free isocyanate monomers in a 3 week old laminate
 - Reason
 - Migration of (pre)polymers
 - High GC injector temperature may cause breakdown of polymers
 - Formation of free isocyanates and diols/diacids
 - Solution
 - Analytical alternatives (e.g. LC-MS)
 - Correlation between injection temperature and detected monomer content?



2. Approaches for adhesive testing

2.2 Polyurethane adhesives


- False-negative results
 - Reaction of isocyanates with food simulants
 - 3% acetic acid: PAA formation
 - Ethanol: urethane formation
 - Vegetable oil: amide formation
 - Solution
 - Determination of reaction products
 - Determination of free isocyanates after extraction with an inert solvent



2. Approaches for adhesive testing

2.3 Choice of detector



- Example 1: PAA analysis
- Unspecific detector (photometer)
 - Easy to handle
 - Sum parameter
 - No structural information
- Specific detector (HPLC-PDA)
 - Instruments required
 - Distinguish between substances
 - No false-positives



2. Approaches for adhesive testing

2.3 Choice of detector


- Example 2: MOSH/MOAH
- Unspecific detector (LC-GC-FID)
 - Proper quantification
 - Sum parameter
 - No structural information
- Specific detector (GCxGC-MS)
 - Technical expertise required
 - Structural information
 - Distinguish between MOAH and other hydrocarbons



2. Approaches for adhesive testing

2.4 Adhesives other than polyurethane adhesives

- Dissolution of aqueous dispersions and hotmelts in liquid simulants
 - Predominant use of liquid simulants according to Plastics Regulation
 - Liquid simulants may re-dissolve the adhesive
 - Extraction rather than migration (worst case)
- High temperature during migration
 - Softening point < 60°C
- Change of physical properties



EVA based adhesive
95% ethanol




Hotmelt 40°C
Hotmelt 60°C

2. Approaches for adhesive testing

2.4 Adhesives other than polyurethane adhesives


- Typical applications
 - Paper and cardboard
 - Secondary/tertiary packaging
- Gas phase transfer
 - Tenax
 - Stored within a distance
- Direct contact on seams and edges
 - Adhesive may be applied on a substrate
 - Tenax in direct contact



2. Approaches for adhesive testing

2.4 Adhesives other than polyurethane adhesives

- Typical applications
 - Paper and cardboard, secondary/tertiary packaging
- Gas phase transfer
 - Headspace analysis as a first screening tool



2. Approaches for adhesive testing

2.4 Adhesives other than polyurethane adhesives


- Heatseals or coldseals may be applied on a substrate and direct food contact cannot be excluded
- Example
 - Heatseal on aluminium substrate
 - Acidic foodstuff
 - Testing with 3% acetic acid
 - Physical change of substrate
 - For testing purposes, an alternative substrate should be selected (e.g. PET)



2. Approaches for adhesive testing

2.4 Adhesives other than polyurethane adhesives

- Pressure sensitive adhesives
 - e.g. dispersions based on acrylic polymers or hotmelts
 - Very tacky, Tenax will stick to the adhesive
 - To test direct contact (e.g. direct labelling), the PSA may be applied on a substrate with no or low barrier properties (paper, thin PE)
 - Migration through substrate, Tenax can be removed easily



3. Summary

- Wide range of applications, complex chemistry of adhesives
- Migration conditions of Regulation (EU) 10/2011 only apply to plastic materials, other approaches are needed for adhesives
- All layers of the FCM should be tested
- False-positives and false-negatives should be considered
- Dissolution of adhesives in liquid food simulants
- Tenax as suitable alternative
- In case of doubt the real application has to be tested